

Each separate building or leased/rented area within a building shall have its own Industrial Pre-treatment Sampling Point ("IPSP"). The IPSP is similar to a cleanout except it has a tee fitting instead of a sweep. Note that sampling at a manhole is no longer allowed. The IPSP is in addition to the cleanouts shown on the plans. The IPSP shall be located in an easily accessible area for possible future sampling. The IPSP must also be located in an unobstructed area that will allow the placement of a 2'x2'x2' sampler that will need to be in-place for a week. The IPSP can be located inside or outside of the building. If the IPSP is located outside the building, it must be in area where there is no vehicular traffic and in area which the sampler will not impede pedestrian traffic. The IPSP must be located where the entire wastewater discharge of the building or leased/rented area is flowing and where no other outside wastewater flows are introduced. The IPSP must be located downstream of any Industrial Pre-treatment facilities (such as grease trap). If you have any question regarding the Industrial Pre-treatment requirements or question about the sampling point locations, call the Industrial Pre-treatment Section at 955-4635 (Raul Martinez). For all other question, please call the Wastewater Management Utility Development Section at 955-4613 or 955-4623 (Douglas Flores or Bryan Romero). **Show the IPSP on the plans.**

